


Air Purifier



OWNER'S MANUAL

AIR PURIFIER

MODEL:FP-71APA040WETH-W

READ AND SAVE THESE INSTRUCTIONS



Imported and distributed by:
CONCEPCION MIDEA INC.
Km. 20, East Service Road, South Superhighway,
Alabang, Muntinlupa, Philippines, 1700

IMPORTANT SAFETY INSTRUCTIONS

Caution

Read Rules for Safe Operation and Instructions Carefully.

WARNING

1. If the supply cord is damaged, it must be replaced by manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
2. To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
4. When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
5. Indoor and household use only.
6. Do not place other items on top of the appliance, and forbid sitting or standing on this appliance.
7. Please use the original filter provided by the factory. In case of other filters, the best results cannot be achieved.
8. Do not insert the fingers or objects into the air inlets or air outlets to prevent the product from physical damages or malfunction.
9. Please unplug the power cord immediately and contact the service center in time when the appliance suffers abnormal sound or burnt smell or smoke.

IMPORTANT SAFETY INSTRUCTIONS

WARNING


10. Do not spray flammable substances near the appliance; Do not spray water directly on the appliance or use chemical cleaners like alcohol or hydrochloric acid, etc.; Do not place water containers, medicines, or flammable materials on the appliance.
11. Do not block the air inlets/outlets of the appliance with any item.
12. This appliance cannot replace natural ventilation and other appliances like the vacuum cleaner, kitchen ventilator, etc.
13. This appliance cannot replace natural ventilation and other appliances like the vacuum cleaner, kitchen ventilator, etc.
14. When the appliance is working, it must be placed on a dry, flat and stable floor, with at least 30cm space reserved around it.
15. Do not put it in a place with direct sunlight.
16. To prevent electromagnetic disturbance, the appliance must keep a certain distance from the TV, radio, microwave oven and others.
17. The mist produced by the ultrasonic humidifier may affect the PM2.5 detection of this appliance, and both should maintain a certain distance.
18. Do not disassemble or modify this appliance without authorization to avoid accidents.
19. Do not pull the power cord to move the appliance.

PRODUCT INTRODUCTION

Notice

Pictures in the manual are for reference only, and real objects within the packaging box will prevail in the end.


Parts name




Product List



Main machine x1




Protective bag x1




Manual x1

PRODUCT INTRODUCTION

Control Panel




Display panel




INSTALLATION INSTRUCTIONS

Installation Steps


- 1** Remove the air inlet grille.
Grasp and pull the clasp in position outward, and remove the air inlet grille.




- 2** Take out the Pre-Filter.
Press the U-shaped buckle to pull outward, and take out the Pre-Filter.




- 3** Take out the HEPA Filter.
Hold both sides of the HEPA Filter with both hands, and take it out.




- 4** Remove the protective film of the filter.



- 5** Install the HEPA Filter.



- 6** Install the Pre-Filter.
Align the slot position at the bottom, and buckle up the upper U-shaped buckle.




INSTALLATION INSTRUCTIONS

Installation Steps


7 Install the air inlet grille.

Align the slot position at the bottom, press both sides of the upper part of the air inlet grille, and buckle up the air inlet grille.



8 Install the filter on the other side.

Repeat steps mentioned in Figure 1-7, to complete installation of the filter on the other side, and plug in the power to operate the machine.



INSTRUCTIONS


Test Run

⚠ Notice

- This machine is provided with a disassembly protection function. The machine can only operate normally after the air inlet grille and air outlet grille are installed properly.
- In case of continuous electricity, it enters the working mode before the standby state after each time of power on.
- The machine is connected to the power again after unexpected power outage (when the power is off or the power cord is unplugged during normal operation), and then restores to the working state before the power outage.

1 Preparations


Power on for the first time, the display panel flashes for 1s, and then the screen is turned off. The whole machine is in the standby state;



Flash for 1s.

2 Switch

On/Off button can be pressed.




INSTRUCTIONS

Test Run


3 Warm up

When the particulate matter sensor enters the warm up state, PM2.5 numerical display shows " ---", and displaying is normal after 10 seconds.



4 Operating

The purifier is powered on for the first time and then enters the automatic mode.



CLEANING AND MAINTENANCE


⚠ Notice

Be sure to turn it off before any maintenance, and cut off power.

Machine body cleaning


Main machine

Wipe the machine body with a soft towel.



Air inlet grille

Open the air inlet grille, vacuum up dust with a vacuum cleaner, and wipe it with a cloth.



CLEANING AND MAINTENANCE

Machine body cleaning


Air outlet grille

Open the air outlet grill, vacuum up dust with a vacuum cleaner, and wipe it with a cloth.




Cleaning of the Filter Components


- 1 When the last bar of the progress bar turns red and the cleaning indicator light is on, it prompts that the Pre-Filter needs to be cleaned.




- 2 Unplug the power plug, and take out the Pre-Filter.



- 3 Vacuum up dust with a vacuum cleaner or wipe it with a cloth.




- 4 If there is a lot of dirt, the common diluted kitchen detergent is used to soak it, and then clean it.




CLEANING AND MAINTENANCE

Cleaning of the Filter Components


5 Dry the Pre-Filter.



6 Install the Pre-Filter.



7 Plug in the power, and turn on the machine for operating.




8 Long press pure ion button for 3 seconds, then the cleaning indicator light is off, and the Pre-Filter is reset.



Replacement of the filter components

1 Filter model: FC-50TB-1A (includes 2 pieces)




2 When the last bar of the progress bar turns red and the replacement indicator light is on, it prompts that the HEPA Filter needs to be replaced.




CLEANING AND MAINTENANCE

Replacement of the filter components


3 Take out the HEPA Filter.



4 Remove the protective film of the filter.



5 Install the HEPA Filter.



6 Hold the pure ion button for 3 seconds to reset the HEPA Filter under other conditions.



Long press for 3 seconds

PRODUCT PARAMETERS

Model	FP-71APA040WETH-W
Rated power supply	230V~ 60Hz
Rated power	40W
CADR (particulate matters)	500m ³ /h
Energy efficiency rating of particulate matters purification	Efficient level
Noise	35-62dB (A)
Usable area	35-60m ²

- The various performance parameters in the table are measured in the factory and for reference only.
- If the product is modified, the parameters may be changed, and please be subject to the parameters on the nameplate.
- The theoretical value of the applicable area is inferred based on the (0.07 - 0.12)×CADR particles; Due to different environments or indoor pollution level and other various factors, the applicable area will also be changed.
- Purification principle: The fan of the air purifier draws air into the body for filtering through the built-in filter element, which plays a main role in filtering the dust (like PM2.5), formaldehyde, odor, sterilization and so on.

SERVICE GUIDE

Troubleshooting

Please check the following points before asking others for inspection or maintenance.

Faults	Processing
The display screen shows "E1"	Disassembly protection tips; Please install the air inlet grille and air outlet grille properly.
The display screen shows "E0"	Hardware fault; Please contact the after-sales office.
The display screen shows "Eu"	Sensor fault; Please contact the after-sales office.
The display screen shows "E3"	The fan speed is beyond control; Please contact the after-sales office.
The purifier does not work	Firstly, check whether the power cord is plugged into the power socket; the loose plug caused by the movement of the purifier may affect the energizing; Secondly, check whether the air inlet grille and air outlet grille of the purifier are installed properly. This product is provided with a disassembly protection function. If the air inlet grille and air outlet grille are not installed properly, the product cannot work.
The purifier has a small amount of air and is noisy	Firstly, check whether the foreign bodies block the air inlet grille and air outlet grille; if any, remove those foreign bodies; Then, check whether the Pre-Filter becomes dirty or reaches the end of its service life; if any, clean the Pre-Filter; Finally, check whether the HEPA Filter is full of dust or reaches the end of its service life; if any, the replacement of the HEPA Filter is required.
The air outlet smells odor	When the product is operated for the first time, it smells slightly plastic, which is normal; If this product works in places (like smoking area or rotisserie, etc.) with strong smell for a long time, the filter element needs to be changed frequently and reset; Check whether the air inlet/outlet grille and Pre-Filter are full of dust or dirt; if any, maintain the machine and clean the dust and dirt on the air inlet/outlet grille and Pre-Filter.
Whether the wheels are pulled out after inserted	If wheels can be pulled out, tilt the machine at a small angle and pull them out with a little effort. If not, try to pull the wheels out while rotating them.
Whether the purifier can be used with the humidifier	The wet environment has a greater impact on the filter element, and the mist produced by the ultrasonic humidifier may cause abnormality in the PM2.5 detection of this product, so that simultaneous operation is avoided as much as possible.