



The design and specifications are subject to change without prior notice for product improvement. Consult with your dealer or manufacturer for details.

A quality product of



CONCEPCION MIDEA INC.



**Midea Customer Care**  
Email: [customercare@midea.com.ph](mailto:customercare@midea.com.ph)  
Toll free: 1-800-10-863-5522  
Landline: (02) 863-55-22  
Viber/SMS: (0917) 863-5522  
Monday - Sunday / 8:00am - 8:00pm

For more information, please visit our website [www.ph.midea.com](http://www.ph.midea.com)

# User's Manual

## PERSONAL BLENDER

FP-74KBP006MTL-B2

Please read this User's Manual carefully for proper use of Midea Personal Blender.



## Contents

IMPORTANT SAFETY INSTRUCTIONS.....	2
PART NAME.....	4
TECHNICAL DATE OF THE PRODUCT .....	5
INSTRUCTIONS FOR USE.....	5
RECIPES.....	6
ABNORMALITY ANALYSIS AND HANDING.....	7
CLEANING AND MAINTENANCE .....	8
CIRCUIT PRINCIPLE DIAGRAM.....	8

IMPORTANT NOTE: Please read the manual carefully before operating your product. Retain it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

To avoid the risk of serious injury when using your blender, basic safety precautions should be followed, including the following.

### **READ ALL INSTRUCTIONS, SAFEGUARDS, AND WARNINGS BEFORE OPERATING BLENDER**

1. There is a potential injury from misuse. Please handle it with care.
  2. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning
  3. This appliance shall not be used by children. Keep the appliance and its cord out of children reach.
  4. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
  5. Children shall not play with the appliance
  6. Be careful when handling the sharp cutting blades, emptying the bowl and during cleaning
  7. Be careful if hot liquid is poured into blender as it can be ejected out of the appliance due to a sudden steaming
  8. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
  9. This appliance is intended to be used in household and similar applications such as:
    - staff kitchen areas in shops, offices and other working environments;
    - farm houses;
    - by clients in hotels, motels and other residential type environments;
    - bed and breakfast type environments.
- appliance EC R This conforms to egulation 1935/2004 on

## IMPORTANT SAFETY INSTRUCTIONS

10. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

**SAVE THESE INSTRUCTION.  
THIS UNIT IS INTENDED FOR HOUSEHOLD USE ONLY.**


### **⚠ Caution:**

Ensure that the blender is switched off before removing.

### **📌 Note**

The failure to follow any of the important safeguards and the important instructions for safe use is a misuse of your personal blender that can void your warranty and create the risk of serious injury.

## PART NAME








No.	Description
1	Lid
2	Jar (0.6l)
3	Blade Assembly
4	Blend body
5	Swith Button


## TECHNICAL DATE OF THE PRODUCT

Product name	Model No.	Rated voltage	Rated frequency	Rated power
PERSONAL BLENDER	FP-74KBP006MTL-B2	230V~	60Hz	230 W

## INSTRUCTIONS FOR USE

 <p>①</p>	<p>Fill the bottle with your favorite ingredients. Be sure not to fill ingredients over the 600ml marking.</p>
 <p>②</p>	<p>Fasten the blade assembly on the open end of the bottle.</p>
 <p>③</p>	<p>Turn the bottle upside down, line up arrow "▲" on the blade assembly to the lock "⊖" on the base, place the bottle in the base by pressing and simply turn the bottle clockwise to lock "⊕" on the base.</p>
 <p>④</p>	<p>Place the blender base on a flat surface and plug in it. Pressing switch, the blender will start to work, release switch to stop working.</p>
 <p>⑤</p>	<p>After the ingredients are fully blended, stop the blender working, and turned counterclockwise rotation the bottle, take out the bottle from the base.</p>

## INSTRUCTIONS FOR USE

 <p>⑥</p>	<p>Replace the blade assembly by use.</p>
--	---

### ⚠ Warning

- ▶ Rotating blades can cause severe injury.
- ▶ DO NOT put hands, spatulas, etc. in the container while the machine is running or while the container is still on the base.
- ▶ Lids is not interchangeable between different container styles, types, and sizes.
- ▶ DO NOT reach into container while machine is running.
- ▶ Machine running time can not be more than 3 minutes. After the shutdown, it is necessary to let it fully heat, cooling to room temperature.

## RECIPES

Item	Food	Quantity	Time
1	Carrot Test Jar capacity 600ml	240g carrot + 360g water	1 mins
2	Crushing ice cubes and water	250g 20mm diameter ice cubes 250g ambient water	1 mins
3	Pineapple smoothie	154g pineapple, skin removed diced, 300ml milk 3pcs ice cubes	15 seconds
4	Kiwi smoothie	168g kiwi, peeled diced 3pcs ice cubes, 300ml milk	15 seconds
5	Banana smoothie	1/2 banana, halved 250ml milk 1 scoop ice cream 1tbsp honey	15 seconds

## ABNORMALITY ANALYSIS AND HANDING

### Abnormality Handling



1. In case of abnormalities such as abnormal noises, smell, smoke, etc., you should immediately cut off power and stop use.
2. If the product cannot work, please check if the power supply is connected, if the switch is put to the ON position and if fittings are installed in place.
3. If the product still cannot work after checks mentioned above, please consult the designated repair centre for maintenance.

### Fault Analysis and Elimination


Symptom	Analysis of Possible Causes	Countermeasure
Product does not work	The jar assembly is not installed in place.	The jar assembly must be closed in place.
	The inching switch is not pressed.	Keep the switch press states.
Blender blade stuck	The amount of processed food is too much.	Reduce the amount of processed food.
	Food sticking the blade.	Switch off electrical power if clean up the ingredients on the clean blade.
The Products found abnormal odor, hot, smoke and other phenomena	The amount of processed food is too much.	Reduce the amount of processed food.
	The product running times too long.	Reduce the motor running times.
	The temperature of the processed ingredients is too high.	Do not exceed 60 °C.
Jar drain juice (water)	The blade holder seal is missing or not properly mounted on the tool holder assembly.	Check the blade holder seal states.
	The jar is screwed into the blade holder assembly without tightening.	Check the jar whether on ttightening.
	The jar is screwed into the jar cover without tightening.	Check the jar whether on ttightening

## CLEANING AND MAINTENANCE

### Cleaning

	<ol style="list-style-type: none"> <li>1. Unplugged from the power source before cleaning.</li> <li>2. Remove all fittings except the main engine for leaning in water. Please be careful when cleaning the blade, sharp blade, to avoid being cut.</li> </ol> <p><b>Note:</b></p> <p>The blade can be disassembled for cleaning, disassembly, a hand glove on the fixed blade, another hand counterclockwise rotation onconnector remove blade, connector, washer for cleaning.</p>
	<ol style="list-style-type: none"> <li>1. Use a damp cloth to wipe the surface of the motor body, with a dry cloth, must not be the main motor body into water or other solution for cleaning, in order to avoid danger.</li> <li>2. After all the parts are dried, the method can be assembled according to the previous method.</li> <li>3. The product has any problem in use, please do not disassemble without permission of the host, should immediately contact the nearest authorized service provider or customer service maintenance point detection, maintenance.</li> </ol>

### CIRCUIT PRINCIPLE DIAGRAM



**重点  
校对项**

- 1. 结构尺寸
- 2. 材质标注
- 3. 物料编码
- 4. 颜色标注
- 5. 客户型号
- 6. 电压功率
- 7. 认证信息
- 8. 条码数字
- 9. 产品名称

项目	
库	
文件名	

尺寸：148X210mm

页码：12页（2页空白页加在最后面）

材质：80G 书纸

印刷颜色：单色印刷（黑色）

印刷版面：双面印刷

装订：骑马钉

注：此说明书仅在说明书16164000003333基础上更改内容，其它无变化参考16164000003333

Midea-BL1189(FP-74KBP006MTL-B2)-0501

		FP-74KBP006MTL-B2	16164000003333
--	--	-------------------	----------------

				<b>说明书</b>				材质:80G 书纸			
标记	处数	更改文件号	签字	日期	图样标记	重量	比例	<b>主力智业（深圳）电器实业有限公司</b>			
制图	罗海燕	认证	徐明旭		∕	K	∕			∕	1:1
设计	-----	标准化	古广君								
校对	-----	审定	黎进凯								
会签	-----	日期	2019-7-9		共 1 页	第 1 页					